

## How to program Doorman remote control

1. Press the 'CODE' button on the drive unit in the garage for one second It displays “Su” or a dot solid
2. Press button 'A' on the new Doorman 2B remote control for one second.
3. Press button 'B' on the new Doorman 2B remote control for one second “Su” or a dot flashes one second and goes out.

That's it! Now you can alternately press button 'A' and button 'B' on the remote control to operate your Doorman garage door opener.

[MagicKey.com.au](http://MagicKey.com.au)