


SK901/ SK902 INSTRUCTION



B&D RED WALL CONTROL BOX

Thank you for purchasing our product. Please follow the steps to do the program, if the remotes do not work straight away.

1. Press LEARN button, which is on the Receiver once, the Signal LED will flash
2. Press one button of the transmitter, Signal LED will be steady.
3. Press the same button of the remote again, LED will flash
4. When the LED stops flashing, the coding sequence is complete.

Delete coding

Press and hold LEARN button until the light is on, all the coding are deleted.